

USAAlert

OWNERS MANUAL



www.usalertllc.com

ICONS

- | | | | |
|---|-------------------|---|--------------------------------|
|  | Vibrate Alert |  | Message Locked |
|  | Beeping Alert |  | Out Of Range Indicator |
|  | Daily Alarm ON |  | Low Battery Indicator |
|  | Duplicate Message |  | Message continues on next page |
|  | Unread Message | | |

FUNCTION KEYS

-  Message **READ** Key
-  **ESCAPE** (back to previous menu)
-  **MENU** Key

Getting Started

Power On – Insert AAA battery and press  **READ Key** for 2 seconds to turn the pager on.



Power Off – Go to the **STANDBY SCREEN**. Press the  **MENU Key** to display the **SETTINGS Menu**. Use the  **MENU Key** to scroll through the menu until **PAGER OFF** is found. Press the  **READ Key** to confirm your choice.

Backlight – Press and hold the  **READ Key** to activate or deactivate.

Read Messages

The pager will display a new message when it is received. To read stored messages, press the  **READ Key** from the **STANDBY SCREEN**. Scroll through messages with the  **READ Key**. You will be returned to the **STANDBY SCREEN** automatically if you scroll to the end of the message queue. If a message is longer than the screen width, the  **READ Key** is used to view the rest of the message.

Delete Messages

While message is displayed – Press the  **MENU Key** to view the **DELETE MENU** Screen.

Using the  **MENU Key**, select between **PROTECT** (locks current message), **DELETE** (deletes current message) or **DELETE ALL** (deletes all stored messages).

Select **PROTECT** (locks current message) to prevent the current message from being deleted.

Press the  **READ Key** to confirm your selection.

The  **ESCAPE Key** takes you back to the **STANDBY SCREEN**.

Settings Menu

Press the  **MENU Key** to select the **SETTINGS Menu**. Scroll through the menu by pressing the  **MENU Key**. Press the  **READ Key** to confirm your selection. Use the  **MENU Key** to modify options. Use the  **READ Key** to move to the next option. To save changes and return to the **STANDBY SCREEN**, press the  **READ Key** until the end of the line is reached.

The  **ESCAPE Key** takes you back to the **STANDBY SCREEN** without saving changes.